

SAMPLING INSTRUCTIONS

Please follow the instructions below **to collect a representative infill sample from your field:**

- Use the diagrams below to collect infill from different locations of your field.
- Take a total weight of approx. 450 g of rubber infill (for instance, take 75g from each locations)
 - Use an exam glove to avoid any external contamination of the infill (food residues for instance).
- Ensure that the rubber infill is free from sand, as much as possible.
- Place your infill sample in a closed transparent clean and single use plastic bag (ex: ZIPLOC Bag).
- Put the bag in a box and ship it using the tag provided by our customer service.



Football



Rugby



Within 48h you will received a shipment tag to ship your sample.

For any question please contact Labosport SYPAC customer service at service.client@laboratoite-sypac.fr or call us at +33 (0)2 37 30 78 80